

# Seeing is Believing®



## **New Filter**

The fuel level in the Fuel Pro starts below the bottom of the half wrap. The filter causes minimal restriction. As the filter is used, dirt collects on the filter from the bottom up.

Fuel rises on the filter, indicating remaining filter life.



## **Fuel Level Remains Below the Half Wrap**

As dirt is trapped in the filter, the fuel level rises over the dirt and flows through the clean filter media to maintain a low flow restriction.



## **Restriction Remains Consistently Low**

While the fuel level remains near the bottom of the half wrap, the fuel is still flowing through clean, new filter media.



## **Ready for Replacement**

The filter is covered by fuel and all of its surface area has been used. Restriction is just starting to rise and the filter should be changed during the next scheduled maintenance.