

AC
AC symbol



AC Plug - 2 pin
AC Plug - 2 pin




Arrow
Arrow




CB-1P
Circuit Breaker, Physical - 1P



CB-2P
Circuit Breaker, Physical - 2P




CB-3P
Circuit Breaker, Physical - 3P




CB-PANEL-1PH
Single-phase breaker panel, 6-space




CB-PANEL-2PH
Two-phase breaker panel, 6-space




CB-PANEL-2PH-LBL
Two-phase breaker panel, 6-space, labels



CB-PANEL-3PH
Three-phase breaker panel, 6-space




CB-PANEL-3PH-LBL
Three-phase breaker panel, 6-space, labels




CB-PANEL-3PH-LBL

Three-phase breaker panel, 6-space, labels



CONN-DELTA

Delta connection (+, -, a, A)




CONN-WYE

Wye (Star) connection (+, -, a, A)




GenSet

Electrical Generator




GenSet (PMG)

Electrical Generator




Generator

Electrical Generator



Generator (PMG)

Electrical Generator




House

House



METER

Generic Meter



METER - kWh - Generic

kWh Meter - Generic




METER-A


Analog Ammeter




METER-A
Analog Ammeter




METER-AMPS
Ammeter




METER-HERTZ
Analog Frequency Meter




METER-HZ
Analog Frequency Meter




METER-KW
Analog Kilowatt meter




METER-KW-3P3W
Yokogawa 10322-xxxx kW meter



METER-KW-3P4W
Yokogawa 10325-xxxx kW meter




METER-KWH
kWh meter



METER-SWBD
Switchboard meter




METER-V
Analog Voltmeter



METER-VOLTS
Analog Voltmeter
Page 3 of 5



METER-VOLTS
Analog Voltmeter




NEMA5-15R
NEMA 5-15R Single AC Receptacle/Outlet




NEMA5-15RD
NEMA 5-15R Duplex AC Receptacle/Outlet




PCC2100
CUMMINS PCC2100 Control Module



PCE15
Watt Transducer




RC-3P
Contactor, Physical - 3P



SCHUKO
SCHUKO AC Receptacle/Outlet (230V)



SCHUKO-D
SCHUKO Duplex AC Receptacle/Outlet (230v)



SENDER-PRESS
Oil Pressure Sender



SENDER-TEMP
Water Temp Sender




START-AIR
Starter - Air/Electric
Page 4 of 5
START-ELEC




START-AIR
 Starter - Air/Electric
 START-ELEC
 Starter - Air/Electric




TX MULTI ISOLATION
 TX Multi-Tap Isolation




TX-1PH OIL
 Transformer, Single-phase Oil-Filled two-bushing




TX-1PH OIL PAR
 Transformer, Single-phase Oil-Filled two-bushing, Parallel Secondary



TX-1PH OIL SCOTT
 Transformer, Single-phase Oil-Filled three-bushing, Scott Connection



TX-3PH OIL
 Transformer, Three-phase Oil-Filled three-bushing



WINDING-90
 90-degree winding



WINDINGS
 30, 90 & 180-degree windings



XL342K5
 Watt Transducer

